




Liquid Freezer III


Pro Series

AIO Liquid CPU Cooler


Intel Quick Start Guide




Thermal Paste Application



Remove Protective Cover



Pump & VRM Installation



Packaging Content



x1



x1

PWM Cable
(Individual Control)

x1

PWM Cable
(All in One)

x1

Metal Flat Washers



x8/x12

Screws



x8/x12

Screws



x8/x12

Shoulder Screws



x4

T20 Driver




x1

MX-6 (0.8 g)




x1


Install Connector Cable



All in One Cable




or



Mounting Installation


*Keep the removed parts for reassembly in the future.

Radiator Installation



Metal Flat Washers x8

Screws x8



Metal Flat Washers x12

Screws x12


PWM & A-RGB Connector

Connector on Cooler


4-Pin 2510 PWM Connector

Connector on Motherboard

4-Pin Header

Plug the Connector
(All in One: 1 Plug
Individual Control: 3 Plugs)

Plug the A-RGB Connector

A-RGB
Header